

ETACS-ECU (FUSE 18)




0.85V


14

V

3



INHIBITOR SWITCH (B-121)




0.850

B-W

Y-L

LG


Y-G



9 (A-63)

13 (A-13)

<RHD>



0

B-W

Y-L

LG

Y-G



- BACK-UP LAMP
- MMCS
- REVERSING SENSOR SYSTEM
- SPARE CONNECTOR (FOR NAVIGATION SYSTEM)
- SPARE CONNECTOR (FOR TRAILER LAMPS)

CVT CONTROL RELAY




0.85V


20 (A-13)

<F>0.75P


1



PRIMARY PULLEY SPEED SENSOR (B-120)




SECONDARY PULLEY SPEED SENSOR (B-118)



SB

B



<F>B

<F>G-W



2 (A-63)




SB

B


G-W

CVT-ECU (C-135)


(A-13)




(A-63)



(B-118)




(B-120)



(B-121)



(C-135)



Wire colour code

B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue  
 BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver