






- NOTE  
\* : -BRAKE WARNING LAMP, FUEL FILTER WARNING LAMP, FUEL WARNING LAMP AND OIL PRESSURE WARNING LAMP  
-CHARGING SYSTEM  
-CRUISE CONTROL SYSTEM  
-DOOR AJAR WARNING BUZZER  
-ENGINE CONTROL SYSTEM  
-FRONT FOG LAMP  
-GLOW SYSTEM  
-HBB, EBD, ABS AND ASTC  
-HEADLAMP
- HEADLAMP AUTOMATIC LEVELLING SYSTEM  
-HEADLAMP WASHER  
-IMMOBILIZER SYSTEM  
-INVECS-II 5A/T  
-METER AND GAUGE  
-REAR DIFFERENTIAL LOCK SYSTEM  
-REAR FOG LAMP  
-REAR WIPER AND WASHER  
-REVERSING SENSOR SYSTEM  
-SEAT BELT WARNING BUZZER
- SECURITY ALARM  
-SPARE CONNECTOR (FOR TRAILER LAMPS)  
-SRS  
-SUPER SELECT 4WD II SYSTEM  
-TAIL LAMP POSITION LAMP AND LIGHTING MONITOR BUZZER  
-TURN-SIGNAL LAMP AND HAZARD WARNING LAMP  
-WINDSHIELD WIPER AND WASHER



Wire colour code  
B : Black LG : Light green G : Green L : Blue W : White Y : Yellow SB : Sky blue  
BR : Brown O : Orange GR : Grey R : Red P : Pink V : Violet PU : Purple SI : Silver